



Automation Gates



By Electric Gates Servicing Ltd

The Barn, Common Farm House, 20 Denby Common, Denby Village, Derbyshire, DE5 8PW
Tel : (01773) 512003 Email : Enquiries@AutomationGates.co.uk <http://www.automationgates.co.uk>

How to change the code on a Camé keypads

Applies to keypads :- S5001, S6001, S7001

1. Choose a new keypad code and write it down. This code can be 3 to 5 digits long.
2. Find the Junction box which contains the printed circuit board with a small button located in the middle to the right hand side.
3. Press the 'E' button on the keypad.
4. Enter the new code into the keypad.
5. Press the 'E' button again.
6. Finally press the yellow button on the PCB. A red LED light should now flash to indicate the new code has been accepted.
7. Before closing the junction box test your keypad with the new code.

